

Compatible Machines

Description	ID	Footnote
IdeaPad D300 series-IdeaPad Duet 3 11IAN8	82XK	
IdeaPad D500 series-IdeaPad Duet 5 12IAU7	82TQ	
IdeaPad D500 series-IdeaPad Duet 5 12IRU8	83B3	
IdeaPad Flex 5 series-IdeaPad 5 2-in-1 14AHP9	83DR	P1. PXE boot supported

[TOP](#)

IdeaPad Flex 5 series-IdeaPad 5 2-in-1 14AKP10	83KT	P1. PXE boot supported
IdeaPad Flex 5 series-IdeaPad 5 2-in-1 14IAL10	83KR	P1. PXE boot supported
IdeaPad Flex 5 series-IdeaPad 5 2-in-1 14IPH11	83UG	Must attach Notebook AC power adapter to system directly to get enough power charging, P1, PXE Boot supported.
IdeaPad Flex 5 series-IdeaPad 5 2-in-1 14IRH9	83KX	P1. PXE boot supported
IdeaPad Flex 5 series-IdeaPad 5 2-in-1 14IRU9	83DT	
IdeaPad Flex 5 series-IdeaPad 5 2-in-1 14Q8X9	83GH	P1. PXE boot supported

TOP

IdeaPad Flex 5 series-IdeaPad 5 2-in-1 14Q8Y11	83UK	Must attach Notebook AC power adapter to system directly to get enough power charging, P1, PXE Boot supported.
IdeaPad Flex 5 series-IdeaPad 5 2-in-1 15IPH11	83UL	Must attach Notebook AC power adapter to system directly to get enough power charging, P1, PXE Boot supported.
IdeaPad Flex 5 series-IdeaPad 5 2-in-1 16AHP9	83DS	P1. PXE boot supported
IdeaPad Flex 5 series-IdeaPad 5 2-in-1 16AKP10	83KU	P1. PXE boot supported
IdeaPad Flex 5 series-IdeaPad 5 2-in-1 16IAL10	83KS	P1. PXE boot supported
IdeaPad Flex 5 series-IdeaPad 5 2-in-1 16IRU9	83DU	

TOP

IdeaPad Flex 5 series-IdeaPad Flex 5 14ABR8	82XX	
IdeaPad Flex 5 series-IdeaPad Flex 5 14IAU7	82TA	
IdeaPad Flex 5 series-IdeaPad Flex 5 14IRU8	82Y0	
IdeaPad Flex 5 series-IdeaPad Flex 5 16ABR8	82XY	
IdeaPad Flex 5 series-IdeaPad Flex 5 16IRU8	82Y1	
IdeaPad Gaming 3 series-IdeaPad Gaming 3 16ARH7	82SC	

[TOP](#)

IdeaPad S300 Series-IdeaPad Slim 3 14IAN8	82XA	
IdeaPad S300 Series-IdeaPad Slim 3 14ITN9	83L6	P1. PXE boot supported
IdeaPad S300 Series-IdeaPad Slim 3 15IAN8	83D7	
	82XB	
IdeaPad S300 Series-IdeaPad Slim 3 15ITN9	83L7	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad 5 14ABA7	82SE	
IdeaPad S500 Series-IdeaPad 5 14IAL7	82SD	

TOP

IdeaPad S500 Series-IdeaPad 5 Pro 16IAH7	82SK	
IdeaPad S500 Series-IdeaPad Pro 5 14AGP11	83SG	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Pro 5 14AKP10	83JL	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Pro 5 14ARP8	83AN	
IdeaPad S500 Series-IdeaPad Pro 5 14ASP10	83LR	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Pro 5 14IAH10	83JK	430.Must attach Notebook AC power adapter to directly to get enough power charging.

TOP

IdeaPad S500 Series-IdeaPad Pro 5 14IPH11	83SH	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Pro 5 14IRH8	83AL	
IdeaPad S500 Series-IdeaPad Pro 5 16AKP10	83JN	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Pro 5 16APH8	83AR	
IdeaPad S500 Series-IdeaPad Pro 5 16ARP8	83AS	
IdeaPad S500 Series-IdeaPad Pro 5 16ASP10	83LS	P1. PXE boot supported

TOP

IdeaPad S500 Series-IdeaPad Slim 5 13ARP10	83J2	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
IdeaPad S500 Series-IdeaPad Slim 5 14AGP11	83S1	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Slim 5 14AHP10	83HV	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Slim 5 14AHP11	83S3	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Slim 5 14AHP9	83DB	
IdeaPad S500 Series-IdeaPad Slim 5 14AKP10	83HX	P1. PXE boot supported

TOP

IdeaPad S500 Series-IdeaPad Slim 5 14ARP10	83HT	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Slim 5 14IAH10	83NC	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Slim 5 14IMH9	83DA	
IdeaPad S500 Series-IdeaPad Slim 5 14IPH11	83S5	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Slim 5 14IRH10	83HR	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Slim 5 14IRH10R	83J0	P1. PXE boot supported

TOP

IdeaPad S500 Series-IdeaPad Slim 5 14IRU9	83FV	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Slim 5 15ARP10	83J3	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
IdeaPad S500 Series-IdeaPad Slim 5 15IRH9R	83J6	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Slim 5 16AGP11	83S2	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Slim 5 16AHP10	83HW	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Slim 5 16AHP11	83S4	P1. PXE boot supported

TOP

IdeaPad S500 Series-IdeaPad Slim 5 16AHP9	83DD	
IdeaPad S500 Series-IdeaPad Slim 5 16AKP10	83HY	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Slim 5 16ARP10	83HU	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Slim 5 16IAH10	83ND	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Slim 5 16IMH9	83DC	
IdeaPad S500 Series-IdeaPad Slim 5 16IPH11	83S6	P1. PXE boot supported

TOP

IdeaPad S500 Series-IdeaPad Slim 5 16IRH10	83HS	P1. PXE boot supported
IdeaPad S500 Series-IdeaPad Slim 5 16IRH10R	83J1	P1. PXE boot supported
IdeaPad S700 Series-IdeaPad Slim 7 Pro 16ACH6	82QR	
IdeaPad S700 Series-Lenovo Slim 7 14IAP7	82SX	
IdeaPad S900 Series-Lenovo Slim 9 14IAP7	82T1	
LOQ 3 Series-LOQ 15IRH8	83EU	
	82XV	

TOP

LOQ 3 Series-LOQ 16IRH8	82XW	
Lenovo 100e Series-100e G4	82W0	
	82W1	
Lenovo 100e Series-100e Intel G4	83G8	
	83G9	
Lenovo 100w Series-100w G4	82VK	PXE boot supported. Wake On LAN from Sleep, Hibernation, or Power-Off mode.MAC address pass through.
	82VL	PXE boot supported. Wake On LAN from Sleep, Hibernation, or Power-Off mode.MAC address pass through.

TOP

Lenovo 100w Series-100w G5	83LD	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	83LE	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Lenovo 13w Series-13w 2-in-1 G3	83M9	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	83MA	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Lenovo 13w Series-13w Yoga	82S2	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	82S1	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

Lenovo 13w Series-13w Yoga G2	82YR	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	82YS	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Lenovo 14e Series- 14e G3	82W6	
	82W7	
Lenovo 300e Series-300e G4	82W2	
	82W3	
Lenovo 300w Series-300w G4	82VM	PXE boot supported. Wake On LAN from Sleep, Hibernation, or Power-Off mode.MAC address pass through.
	82VN	PXE boot supported. Wake On LAN from S Hibernation, or Power-Off mode.MAC address pass through.

TOP

Lenovo 300w Series-300w G5	83LF	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	83LG	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Lenovo 500e Series-500e G4	82W5	
	82W4	
Lenovo 500w Series-500w G4	82VQ	PXE boot supported. Wake On LAN from Sleep, Hibernation, or Power-Off mode.MAC address pass through.
	82VR	PXE boot supported. Wake On LAN from Sleep, Hibernation, or Power-Off mode.MAC address pass through.

TOP

Lenovo 500w	83LH	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Series-500w G5	83LJ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Lenovo Chrome Plus-Chrome Plus	83LM	
2in1 Intel	83LL	
Lenovo Flex 7 Series-Lenovo Flex 7 14IAU7	82VC	
Lenovo Flex 7 Series-Lenovo Flex 7 14IRU8	82Y2	

TOP

Lenovo Flex5 Chromebook Series-Lenovo Flex5 Chrome 14IAU	83AK	
	83AJ	
Lenovo K14 Series-K14 AMD G1	21CV	P1. PXE boot supported
	21CU	P1. PXE boot supported
Lenovo K14 Series-K14 G1	21CS	P1. PXE boot supported
	21CT	P1. PXE boot supported
Lenovo K14 Series-K14 G2	21G0	
	21G1	
Lenovo S700 Series-Lenovo Slim 7 14IMH9	83D8	

TOP

Lenovo S700 Series-Lenovo Slim 7 14IRP8	83A4	
Lenovo S700 Series-Lenovo Slim 7 16ARH7	82UX	
Lenovo S700 Series-Lenovo Slim 7 16IAH7	82VB	
Lenovo S700 Series-Lenovo Slim 7 ProX 14IAH7	82V1	
Lenovo S700 Series-Lenovo Slim Pro 7 14APH8	83AW	

[TOP](#)

Lenovo S700 Series-Lenovo Slim Pro 7 14ARP8	83AX	
Lenovo S900 Series-Lenovo Slim Pro 9 16IRP8	83C0	
ThinkBook Plus Series-ThinkBook Plus G3 IAP	21EL	430.Must attach Notebook AC power adapter to system directly to get enough power charging.
ThinkBook Plus Series-ThinkBook Plus G4 IRU	21JJ	
ThinkBook Plus Series-ThinkBook Plus G6 Rollable	21TR	P1W45.PXE boot supported Wake On LAN from Hibernation,Power-Off mode

TOP

ThinkBook Series (Performance)- ThinkBook 14p G3 ARH	21EJ	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
ThinkBook Series (Performance)- ThinkBook 15p G2 ITH	21B1	430.Must attach Notebook AC power adapter to system directly to get enough power charging.
ThinkBook Series (Performance)- ThinkBook 16p G3 ARH	21EK	430.Must attach Notebook AC power adapter to system directly to get enough power charging.
ThinkBook Series (Performance)- ThinkBook 16p G4 IRH	21J8	430.Must attach Notebook AC power adapter to system directly to get enough power charging.

TOP

ThinkBook Series (Performance)- ThinkBook 16p G5 IRX	21N5	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
ThinkBook Series (Performance)- ThinkBook 16p G6 AFR	21U1	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45 PXE boot supported Wake On LAN from Hibernation,Power-Off mode supported
ThinkBook Series (Performance)- ThinkBook 16p G6 IAX	21R0	430.Must attach Notebook AC power adapter to system directly to get enough power charging.
ThinkBook Series (Performance)- ThinkBook 16p NX ARH	21EV	430.Must attach Notebook AC power adapter to system directly to get enough power charging.

TOP

ThinkBook Series (Performance)- family not used	21EU	430.Must attach Notebook AC power adapter to system directly to get enough power charging.
ThinkBook Slim Series-ThinkBook 13s G4 ARB	21AS	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkBook Slim Series-ThinkBook 13s G4 IAP	21AR	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkBook Slim Series-ThinkBook 13s G5 IRP	21JA	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkBook X series-ThinkBook 13x G2 IAP	21AT	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkBook X series-ThinkBook 13x G4 IMH	21KR	

TOP

ThinkBook Yoga Series-ThinkBook 14 2-in-1 G4 IML	21MX	P1. PXE boot supported
ThinkBook Yoga Series-ThinkBook 14 2-in-1 G5 IAU	21SQ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkBook Yoga Series-ThinkBook 14s Yoga G2 IAP	21DM	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkBook Yoga Series-ThinkBook 14s Yoga G3 IRU	21JG	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad C14 Series-C14 G1 Chromebook	21CA	Dock Firmware updates on Windows-based host systems only. Not support PXE boot, Wake On LAN from Sleep, Power-Off mode, MAC address pass through.
	21C9	Dock Firmware updates on Windows-based host systems only. Not support PXE boot, Wake On LAN from Sleep, Power-Off mode, MAC address pass through.
ThinkPad E14 Series-E14 AMD G4	21EC	PXE boot supported.MAC address pass through supported
	21EB	PXE boot supported.MAC address pass through supported
ThinkPad E14 Series-E14 AMD G5	21JR	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21JS	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad E14 Series-E14 AMD G6	21M4	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21M3	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad E14 Series-E14 AMD G7	21T0	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21T1	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad E14 Series-E14 G4	21E3	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21E4	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad E14 Series-E14 G5	21JK	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21JL	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad E14 Series-E14 G6	21M8	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21M7	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

[TOP](#)

ThinkPad E14 Series-E14 G7	21U2	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21TA	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21SX	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21SY	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21U3	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21T9	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad E15 Series-E15 AMD G4	21ED	PXE boot supported.MAC address pass through supported
	21EE	PXE boot supported.MAC address pass through supported
ThinkPad E15 Series-E15 G4	21E7	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21E6	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad E16 series-E16 AMD G1	21JU	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21JT	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad E16 series-E16 AMD G2	21M5	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21M6	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad E16 series-E16 AMD G3	21SU	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21ST	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad E16 series-E16 G1	21JQ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21JN	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

[TOP](#)

ThinkPad E16 series-E16 G2	21MB	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21MA	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

[TOP](#)

ThinkPad E16 series-E16 G3	22AY	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21TF	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21SS	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	22B0	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21SR	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21TG	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad L13 Series-L13 2-in-1 G5	21LN	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21LM	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L13 Series-L13 2-in-1 G6	21R7	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21R8	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L13 Series-L13 AMD 2- in-1 G6	21RE	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21RD	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad L13 Series-L13 AMD G6	21RB	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21RC	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L13 Series-L13 Clam AMD G2	21AB	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21AC	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L13 Series-L13 Clam AMD G3	21B9	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21BA	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad L13 Series-L13 Clam AMD G4	21FQ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21FN	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L13 Series-L13 Clam G3	21B3	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21B4	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L13 Series-L13 Clam G4	21FG	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21FH	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad L13 Series-L13 Clam G5	21LC	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21LB	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L13 Series-L13 G6	21R5	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21R6	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L13 Series-L13 Yoga AMD G2	21AE	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21AD	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad L13 Series-L13 Yoga AMD G3	21BB	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21BC	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L13 Series-L13 Yoga AMD G4	21FR	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21FS	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L13 Series-L13 Yoga G3	21B6	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21B5	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad L13 Series-L13 Yoga G4	21FK	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21FJ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L14 Series-L14 AMD G3	21C5	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21C6	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L14 Series-L14 AMD G4	21H6	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21H5	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad L14 Series-L14 AMD G5	21L6	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21L5	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L14 Series-L14 AMD G6	21SE	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21S9	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21SF	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21S8	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad L14 Series-L14 AMD G7	21X6	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21X7	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L14 Series-L14 G3	21C2	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21C1	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L14 Series-L14 G4	21H1	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21H2	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad L14 Series-L14 G5	21L2	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21L1	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L14 Series-L14 G6	21S6	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21S7	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L15 Series-L15 AMD G3	21C7	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21C8	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad L15 Series-L15 AMD G4	21H7	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21H8	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L15 Series-L15 G3	21C3	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21C4	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L15 Series-L15 G4	21H3	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21H4	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad L16 Series-L16 AMD G1	21L8	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21L7	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L16 Series-L16 AMD G2	21SC	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21RH	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21RJ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21SD	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad L16 Series-L16 AMD G3	21XC	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21XD	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L16 Series-L16 G1	21L4	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21L3	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad L16 Series-L16 G2	21SA	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21SB	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad P1 Series-P1 G5	21DC	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21DD	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
ThinkPad P1 Series-P1 G6	21FW	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21FV	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
ThinkPad P1 Series-P1 G7	21KV	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21KW	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
ThinkPad P1 Series-P1 G8	21Q8	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21Q9	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W

[TOP](#)

ThinkPad P14 Series-P14s AMD G3	21J5	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21J6	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad P14 Series-P14s AMD G4	21K6	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21K5	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad P14 Series-P14s AMD G5	21MF	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21ME	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad P14 Series-P14s AMD G6	21QL	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21QM	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21RV	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21RW	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad P14 Series-P14s G3	21AL	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21AK	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad P14 Series-P14s G4	21HG	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21HF	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad P14 Series-P14s G5	21G2	PXE boot supported. Wake On LAN from Hibernation, Power-Off mode.MAC address pass through. Must attach notebook AC power adapter to system directly to support rapid power charging if adapter included with the notebook is 135W.
	21G3	PXE boot supported. Wake On LAN from Hibernation, Power-Off mode.MAC address pass through. Must attach notebook AC power adapter to system directly to support rapid power charging if adapter included with the notebook is 135W.

TOP

ThinkPad P14 Series-P14s G6	21QU	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21QT	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad P15 Series-P15v AMD G3	21EM	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21EN	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
ThinkPad P15 Series-P15v G3	21D8	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21D9	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1

TOP

ThinkPad P15 Series-T15p G3	21DA	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21DB	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
ThinkPad P16 Series-P16 G1	21D6	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21D7	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
ThinkPad P16 Series-P16 G2	21FB	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21FA	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
ThinkPad P16 Series-P16 G3	21RR	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21RQ	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W

[TOP](#)

ThinkPad P16 Series-P16s AMD G1	21CK	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21CL	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad P16 Series-P16s AMD G2	21K9	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21KA	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad P16 Series-P16s AMD G4	21QR	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21RY	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21RX	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21QS	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad P16 Series-P16s G1	21BU	PXE boot supported. Wake On LAN from Hibernation, Power-Off mode.MAC address pass through. Must attach notebook AC power adapter to system directly to support rapid power charging if adapter included with the notebook is 135W.
	21BT	PXE boot supported. Wake On LAN from Hibernation, Power-Off mode.MAC address pass through. Must attach notebook AC power adapter to system directly to support rapid power charging if adapter included with the notebook is 135W.

ThinkPad P16 Series-P16s G2	21HL	PXE boot supported. Wake On LAN from Hibernation, Power-Off mode.MAC address pass through. Must attach notebook AC power adapter to system directly to support rapid power charging if adapter included with the notebook is 135W.
	21HK	PXE boot supported. Wake On LAN from Hibernation, Power-Off mode.MAC address pass through. Must attach notebook AC power adapter to system directly to support rapid power charging if adapter included with the notebook is 135W.

ThinkPad P16 Series-P16s G3	21KT	PXE boot supported. Wake On LAN from Hibernation, Power-Off mode.MAC address pass through. Must attach notebook AC power adapter to system directly to support rapid power charging if adapter included with the notebook is 135W.
	21KS	PXE boot supported. Wake On LAN from Hibernation, Power-Off mode.MAC address pass through. Must attach notebook AC power adapter to system directly to support rapid power charging if adapter included with the notebook is 135W.
ThinkPad P16 Series-P16s G4	21QW	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21QV	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad P16 Series-P16v AMD G1	21FF	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21FE	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
ThinkPad P16 Series-P16v G1	21FD	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21FC	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
ThinkPad P16 Series-P16v G2	21KY	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21KX	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
ThinkPad P16 Series-P16v G3	21RS	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21RT	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W

[TOP](#)

ThinkPad T1 Series-T1g G8	21TD	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21TE	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
ThinkPad T14 Series-T14 AMD G3	21CF	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21CG	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad T14 Series-T14 AMD G4	21K4	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21K3	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad T14 Series-T14 AMD G5	21MC	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21MD	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad T14 Series-T14 AMD G6	21QK	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21QJ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad T14 Series-T14 G3	21AH	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21AJ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad T14 Series-T14 G4	21HD	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21HE	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad T14 Series-T14 G5	21ML	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21MM	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad T14 Series-T14 G6	21QC	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21QD	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21QH	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21QG	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad T14 Series-T14 G7	21WN	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21WQ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad T14 Series-T14s 2-in-1 G1	21R4	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21R3	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad T14 Series-T14s AMD G4	21F9	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21F8	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad T14 Series-T14s AMD G6	21M1	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21TC	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21M2	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21TB	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad T14 Series-T14s G3	21BR	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21BS	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad T14 Series-T14s G4	21F6	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21F7	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad T14 Series-T14s G5	21LS	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21LT	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad T14 Series-T14s G6	21QX	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21R1	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21QY	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21R2	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad T14 Series-T14s Snapdragon G6	21N1	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21N2	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad T16 Series-T16 AMD G1	21CH	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21CJ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad T16 Series-T16 AMD G2	21K7	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21K8	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad T16 Series-T16 AMD G4	21QQ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21QN	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad T16 Series-T16 G1	21BW	PXE boot supported. Wake On LAN from Hibernation, Power-Off mode.MAC address pass through. Must attach notebook AC power adapter to system directly to support rapid power charging if adapter included with the notebook is 135W.
	21BV	PXE boot supported. Wake On LAN from Hibernation, Power-Off mode.MAC address pass through. Must attach notebook AC power adapter to system directly to support rapid power charging if adapter included with the notebook is 135W.
ThinkPad T16 Series-T16 G2	21HH	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21HJ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad T16 Series-T16 G3	21MN	PXE boot supported. Wake On LAN from Hibernation, Power-Off mode.MAC address pass through. Must attach notebook AC power adapter to system directly to support rapid power charging if adapter included with the notebook is 135W.
	21MQ	PXE boot supported. Wake On LAN from Hibernation, Power-Off mode.MAC address pass through. Must attach notebook AC power adapter to system directly to support rapid power charging if adapter included with the notebook is 135W.
ThinkPad T16 Series-T16 G4	21QE	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21QF	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad T16 Series-T16 G5	21WT	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21WU	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
ThinkPad T16g Series-T16g G3	21V6	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21V5	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1

TOP

ThinkPad X1 series-X1 2-in-1 G10	21NV	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21Q1	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21NU	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21Q0	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X1 series-X1 2-in-1 G11	21V9	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21VA	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad X1 series-X1 2-in-1 G9	21KE	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21KF	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X1 series-X1 Carbon G10	21CC	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21CB	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X1 series-X1 Carbon G11	21HM	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21HN	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad X1 series-X1 Carbon G12	21KC	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21KD	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X1 series-X1 Carbon G13	21NS	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21NT	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21NX	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21NY	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad X1 series-X1 Carbon G14	21V7	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21V8	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X1 series-X1 Extreme G5	21DE	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21DF	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
ThinkPad X1 series-X1 Fold 16 G1	21ES	PXE boot supported.MAC address pass through supported
	21ET	PXE boot supported.MAC address pass through supported

TOP

ThinkPad X1 series-X1 Nano G2	21E8	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21E9	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X1 series-X1 Nano G3	21K2	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21K1	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X1 series-X1 Yoga G7	21CD	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21CE	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad X1 series-X1 Yoga G8	21HR	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21HQ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X12 Series-X12 Detachable G2	21LL	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21LK	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X13 series-X13 2-in-1 G5	21LW	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21LX	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad X13 series-X13 AMD G4	21J4	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21J3	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X13 series-X13 AMD G6	21RM	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21RN	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X13 series-X13 G3	21BN	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21BQ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad X13 series-X13 G4	21EX	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21EY	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X13 series-X13 G5	21LV	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21LU	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X13 series-X13 G6	21RK	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21RL	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad X13 series-X13 G7	21YH	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21YJ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X13 series-X13 Yoga G3	21AW	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21AX	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X13 series-X13 Yoga G4	21F2	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21F3	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad X13 series-X13s G1	21BY	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21BX	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X9- ThinkPad X9-14 G1	21QA	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21QB	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad X9- ThinkPad X9-15 G1	21Q6	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21Q7	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

ThinkPad Z13 Series-Z13 AMD G1	21D3	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21D2	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad Z13 Series-Z13 AMD G2	21JV	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21JW	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
ThinkPad Z16 Series-Z16 AMD G1	21D4	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21D5	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W

TOP

ThinkPad Z16 Series-Z16 AMD G2	21JX	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21JY	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
Thinkbook Series- ThinkBook 14 G4 ABA	21DK	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 14 G4 IAP	21DH	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 14 G4+ ARA	21D0	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
Thinkbook Series- ThinkBook 14 G4+ IAP	21CX	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

Thinkbook Series- ThinkBook 14 G5 ABP	21JE	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 14 G5 IRL	21JC	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 14 G6 ABP	21KJ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 14 G6 IRL	21KG	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 14 G6 IRL Brazil	21NQ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 14 G7 ARP	21MV	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

Thinkbook Series- ThinkBook 14 G7 IML	21NC	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21MR	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 14 G8 IAL	21SJ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 14 G8 IRL	21SG	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21TV	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

Thinkbook Series- ThinkBook 14 G9 IRL	21UU 21UY	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1 Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
Thinkbook Series- ThinkBook 15 G4 ABA	21DL	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 15 G4 IAP	21DJ	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 15 G5 ABP	21JF	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 15 G5 IRL	21JD	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

Thinkbook Series- ThinkBook 16 G4+ ARA	21D1	430.Must attach Notebook AC power adapter to system directly to get enough power charging.
Thinkbook Series- ThinkBook 16 G4+ IAP	21CY	430.Must attach Notebook AC power adapter to system directly to get enough power charging.
Thinkbook Series- ThinkBook 16 G6 ABP	21KK	
Thinkbook Series- ThinkBook 16 G6 IRL	21KH	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 16 G6 IRL Brazil	21NR	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 16 G7 ARP	21MW	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

Thinkbook Series- ThinkBook 16 G7 IML	21ND	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21MS	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 16 G7 QOY	21NH	P1W45.PXE boot supported Wake On LAN from Hibernation,Power-Off mode
Thinkbook Series- ThinkBook 16 G7+ ASP	21Q5	PXE boot supported. Wake On LAN from Sleep, Hibernation, or Power-Off mode.MAC address pass through.
Thinkbook Series- ThinkBook 16 G8 IAL	21SK	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

Thinkbook Series- ThinkBook 16 G8 IRL	21TW	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	21SH	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Thinkbook Series- ThinkBook 16 G9 IRL	21UV	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
	21US	Must attach Notebook AC power adapter to system directly to get enough power charging. P1W45M1
V Series-Lenovo V14 G4 AMN	83MB	Notebook power button mirroring function is not available with this dock
	82YT	
V Series-Lenovo V14 G4 AMN(Brazil)	83GE	Notebook power button mirroring function is not available with this dock

TOP

V Series-Lenovo V14 G4 IRU	83A0	Notebook power button mirroring function is not available with this dock
V Series-Lenovo V14 G5 IRL	83GU	PXE boot supported.MAC address pass through supported
	83HD	PXE boot supported.MAC address pass through supported
V Series-Lenovo V14 G6 ITN	83M3	PXE boot supported.MAC address pass through supported
V Series-Lenovo V15 G4 AMN	83CQ	Notebook power button mirroring function is not available with this dock
	82YU	Notebook power button mirroring function is not available with this dock
V Series-Lenovo V15 G4 AMN(Brazil)	83UY	Notebook power button mirroring function is not available with this dock
V Series-Lenovo V15 G4 IRU	83A1	Notebook power button mirroring function available with this dock

TOP

V Series-Lenovo V15 G5 IRL	83HF	PXE boot supported.MAC address pass through supported
V Series-Lenovo V15 G6 ITN	83GW	PXE boot supported.MAC address pass through supported
V Series-Lenovo V17 G4 IRU	83A2	Notebook power button mirroring function is not available with this dock
Yoga C600 Series- Yoga 6 13ABR8	83B2	
Yoga C700 Series- Yoga 7 14ARP8	82YM	
Yoga C700 Series- Yoga 7 14IRL8	82YL	
Yoga C700 Series- Yoga 7 16ARP8	83BS	

TOP

Yoga C700 Series- Yoga 7 16IRL8	82YN	
Yoga C700 Series- Yoga 7 2-in-1 14AHP9	83DK	P1W45.PXE boot supported Wake On LAN from Hibernation,Power-Off mode
Yoga C700 Series- Yoga 7 2-in-1 14AKP10	83JR	P1. PXE boot supported
Yoga C700 Series- Yoga 7 2-in-1 14ILL10	83JQ	P1. PXE boot supported
Yoga C700 Series- Yoga 7 2-in-1 14IPH11	83TC	P1W45.PXE boot supported Wake On LAN from Hibernation,Power-Off mode
Yoga C700 Series- Yoga 7 2-in-1 16AHP9	83DM	P1W45.PXE boot supported Wake On LAN from Hibernation,Power-Off mode

TOP

Yoga C700 Series- Yoga 7 2-in-1 16AKP10	83JU	P1. PXE boot supported
Yoga C700 Series- Yoga 7 2-in-1 16ILL10	83JT	P1. PXE boot supported
Yoga C700 Series- Yoga 7 2-in-1 16IPH11	83TE	P1W45.PXE boot supported Wake On LAN from Hibernation,Power-Off mode
Yoga C900 Series- Yoga 9 2-in-1 14ILL10	83LC	P1. PXE boot supported
Yoga C900 Series- Yoga 9 2-in-1 14IMH9	83AC	P1. PXE boot supported
Yoga C900 Series- Yoga Book 9 13IMU9	83FF	P1. PXE boot supported

TOP

Yoga C900 Series- Yoga Book 9 13IRU8	82YQ	
Yoga C900 Series- Yoga Book 9 14IAH10	83KJ	
Yoga S600 Series- Yoga Slim 6 14APU8	83BL	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
	82X3	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Yoga S600 Series- Yoga Slim 6 14IAP8	82WU	
	83C7	
Yoga S600 Series- Yoga Slim 6 14IRH8	83E0	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through

TOP

Yoga S600 Series- Yoga Slim 6 14IRP8	82WV	
Yoga S700 Series- Yoga Pro 7 14AHP9	83E3	P1. PXE boot supported
Yoga S700 Series- Yoga Pro 7 14AKP10	83KG	P1. PXE boot supported
Yoga S700 Series- Yoga Pro 7 14APH8	82Y8	P1W45M1. PXE boot supported. Wake On LAN from Hibernation,Power-Off mode.MAC address pass through
Yoga S700 Series- Yoga Pro 7 14ARP8	83AU	
Yoga S700 Series- Yoga Pro 7 14ASP10	83LX	P1. PXE boot supported

TOP

Yoga S700 Series- Yoga Pro 7 14IAH10	83KF	Must attach Notebook AC power adapter to system directly to get enough power charging, P1, PXE Boot supported.
Yoga S700 Series- Yoga Slim 7 14AGP11	83QS	Must attach Notebook AC power adapter to system directly to get enough power charging, P1, PXE Boot supported.
Yoga S700 Series- Yoga Slim 7 14AKP10	83JY	P1. PXE boot supported
Yoga S700 Series- Yoga Slim 7 14IMH9	83CV	
	83GM	P1. PXE boot supported
Yoga S700 Series- Yoga Slim 7 14IPH11	83QM	Must attach Notebook AC power adapter to system directly to get enough power charging, P1, PXE Boot supported.
Yoga S700 Series- Yoga Slim 7 Pro 14IAH7	82UT	

TOP

Yoga S700 Series- Yoga Slim 7 Pro 14IAP7	82SV	
Yoga S700 Series- Yoga Slim 7 Pro 16ACH6	82QQ	
Yoga S700 Series- Yoga Slim 7 Pro 16ARH7	82UW	
Yoga S700 Series- Yoga Slim 7 Pro 16IAH7	82VA	
Yoga S700 Series- Yoga Slim 7 ProX 14IAH7	82TK	
Yoga S900 Series- Yoga Pro 9 16IAH10	83L0	P1. PXE boot supported

TOP

Yoga S900 Series- Yoga Pro 9 16IRP8	83BY	430.Must attach Notebook AC power adapter to system directly to get enough power charging.
Yoga S900 Series- Yoga Slim 9 14IAP7	82T0	
Yoga S900 Series- Yoga Slim 9 14ILL10	83CX	P1. PXE boot supported